

- 1 Install temporary "traffic control change ahead" min 100' from stop signs. Remove aft 90 days
- 2 Install 30x30 retroreflective R1-1 stop signs on Telespar poles per PW Detail drawings
- 3 Install 2' x 10' cosmopolitin thermoplastic crosswalks per PW Detail drawings
- 4 Set out temporary barricade mounted stop signs to facilitate traffic control change. Remove after 7 days
- 5 Place no parking barricades as needed in parking spaces to ensure all traffic control is visible and unblocked.



Heintz at Molalla Ave - All Way Stop

Revisions
2/15/18 initial release
Scale
Not to scale
Approvals
Draftsman: Andy Peters
Approved by: Gerald Fisher

